




Cordless Caulking Gun

Item No : DCG-101



● The consumable parts ▲ The replacement parts ★ The non-replacement parts



Part List DCG-101

	NO.	PART NO.	DESCRIPTION	Q'TY
▲	2	DCG-101P02	CARTRIDGE HOLDER	1
▲	4	DCG-101P04	CARTRIDGE PLUNGER	1
▲	5	DCG-101P05	PAN HEAD SCREW	1
▲	6	DCG-101P06	RACK	1
●	7	DCG-101P07	FIX NUT	1
●	8	DCG-101P08	FLAT GASKET	1
●	9	DCG-101P09	LOCK GASKET	1
●	10	DCG-101P10	FLAT GASKET	1
●	11	DCG-101P11	GEARBOX ASS'Y	1
▲	12	DCG-101P12	STROKE STAND	1
★	13	DCG-101T13	RIGHT & LEFT HOUSING	1 SET
▲	14	DCG-101P14	RACK HOOK	1
★	15	DCG-101P15	FIX SCREW	1
▲	16	DCG-101P16	CLUTCH BUTTON	1
▲	17	DCG-101P17	MOTOR ASS'Y	1
★	18	DCG-101P18	PCB ASS'Y	1
★	19	DCG-101P19	LIMIT MICRO SWITCH	1
▲	20	DCG-101P20	SWITCH	1
★	21	DCG-101P21	SPEED KNOB	1
★	22	DCG-101P22	WORKING ILLUMINATION LED	1
▲	23	DCG-101P23	BATTERY TERMINAL	1