




1/4" Air Die Grinder Item No : QA-688



Part List QA-688



NO.	PART NO.	DESCRIPTION	Q'TY	NO.	PART NO.	DESCRIPTION	Q'TY
1	QA-688P01	Housing	1	25	QA-688P25	Retainer Ring (d10.2*T1)	1
2	QA-688P02	Washer (M8)	1	26	---	O-Ring (S8) (2pcs)	1 SET
3	QA-688P03	Valve Plug	1	27	QA-688T27	Throttle Valve (26,27)	1 SET
4	QA-688T04	O-Ring (W1.2*d8) (3pcs)	1 SET	28	QA-688P28	Valve Stem	1
5	QA-688P05	Shaft	1	29	QA-688P29	Handle	1
6	QA-688P06	Gasket	1	30	QA-688P30	Spring Pin (D3*L26)	1
7	QA-688P07	End Cap	1	31	QA-688P31	Throttle Lever	1
8	QA-688T08	O-Ring (W1*d3) (2pcs)	1 SET	32	QA-688P32	Grip	1
9	QA-688T09	Screw (M4*P0.7*L8) (2pcs)	1 SET	33	QA-688P33	Decorations	1
10	QA-688P10	O-Ring (w1.3*d36.5)	1	34	QA-688P34	Decorations	1
11	QA-688P11	Ball Bearing (626ZZ)	1	35	QA-688P35	Valve Seat	1
12	QA-688P12	Rear End Plate	1	36	QA-688P36	Oil seal	1
13	QA-688P13	Rotor	1	37	QA-688P37	Valve	1
14	QA-688T14	Rotor Blade (4pcs)	1 SET	38	QA-688P38	Valve Spring	1
15	QA-688T15	Cylinder with Spring Pin (D2*L6)	1 SET	39	QA-688P39	O-Ring (W1.5*d15)	1
16	QA-688P16	Front End Plate	1	40	QA-688P40	Air Inlet Bushing	1
17	QA-688P17	Washer	1	41	QA-688P41	Wrench	1
18	QA-688P18	Ball Bearing (EE4)	1	42	QA-688P42	Wrench	1
19	QA-688P19	Exhaust ring	1	43	QA-688P43	Wrench	1
20	QA-688P20	O-Ring (w1.5*d31)	1				
21	QA-688P21	Connect Nut	1				
22	QA-688P22	Collets Holder	1				
23	QA-688P23A	6mm Collet	1				
	QA-688P23B	1/4" Collet	1				
24	QA-688P24	Collet Nut	1				