




Air Angle Grinder Item No : QB-104



● The consumable parts ▲ The replacement parts ★ The non-replacement parts



Part List QB-104

NO.	INDEX NO.	DESCRIPTION	Q'TY
★ 01	QB-104P01	Motor Housing	1
▲ 02	QB-104P02	Seal Plate	1
★ 03	QB-104P03	Ball Bearing	1
★ 04	QB-104P04	Arbor	1
● 05	QB-104P05	Ball Bearing	1
▲ 06	QB-104P06	Woodruff Key	1
X 07	---	Bevel Gear	1
★ 08	QB-104P08	Wave Washer	1
▲ 09	QB-104P09	Retaining Ring	1
● 10	QB-104P10	Gasket	1
★ 11	QB-104P11	Retainer	1
★ 12	QB-104P12	Wheel Guard	1
★ 14	QB-104T14	Cap Bolt (5 pcs)	1 set
★ 15	QB-104P15	Rotor	1
▲ 16	QB-104P16	Front End Plate	1
★ 17	QB-104P17	Cylinder	1
★ 18	QB-104P18	Spring Pin	1
● 19	QB-104T19	Rotor Blade (4 pcs)	1 set
▲ 20	QB-104P20	Rear End Plate	1
X 21	---	Governor	1
X 22	---	Pendulum	8
X 23	---	Spring Pin	2
X 24	---	Plunger	1
X 25	---	Adjust Screw	1
X 26	---	Spring	1
X 27	---	Adjust Nut	1
● 28	QB-104P28	Ball Bearing	1
X 29	---	Bevel Pinion	1
▲ 30	QB-104P30	O-Ring	1
★ 31	QB-104P31	Governor Housing	1
★ 32	QB-104P32	Valve Stem	1
★ 33	QB-104P33	Roller Pin	1
★ 34	QB-104P34	Valve Ring	1
★ 35	QB-104P35	Valve Spring	1
★ 36	QB-104P36	Steel Ball	1
★ 37	QB-104P37	Coil Spring	1
★ 38	QB-104P38	Air Inlet Joint	1
★ 39	QB-104P39	Exhaust Deflector	1
★ 40	QB-104T40	Tapping Screw (2 pcs)	1 set
★ 41	QB-104P41	Grease Inlet Plug	1
▲ 42	QB-104P42	O-Ring	1
★ 43	QB-104P43	Wheel Flange	1
★ 44	QB-104P44	Rubber Shield	1
● 45	QB-104P45	Grinding Wheel (QB-904)	1
★ 46	QB-104P46	Wheel Clamp	1
★ 47	QB-104P47	Handle	1
★ 48	QB-104P48	Wheel Wrench (A)	1
★ 49	QB-104P49	Wheel Wrench (B)	1
▲ 50	QB-104T50	Ball Bearing (2 pcs)	1 set
★ 67	QB-104P67	Grip	1
★	QB-104T01	Governor Assembly (21.22.23.24.25.26.27)	1set
●	QB-104T02	Bevel Gear Assembly (07.29)	1set