




Air Angle Grinder

Item No : QB-105



● The consumable parts ▲ The replacement parts ★ The non-replacement parts



Part List QB-105

	NO.	INDEX NO.	DESCRIPTION	Q'TY
★	01	QB-105P01	Motor Housing	1
▲	02	QB-105P02	Seal Plate	1
▲	03	QB-105P03	Ball Bearing	1
★	04	QB-105P04	Arbor	1
●	05	QB-105P05	Ball Bearing	1
▲	06	QB-105P06	Woodruff Key	1
x	07	---	Bevel Gear	1
★	08	QB-105P08	Wave Washer	1
▲	09	QB-105P09	Retaining Ring	1
●	10	QB-105P10	Gasket	1
★	11	QB-105P11	Retainer	1
★	12	QB-105P12	Wheel Guard	1
★	14	QB-105T14	Cap Bolt (5 pcs)	1 set
★	15	QB-105P15	Rotor	1
▲	16	QB-105P16	Front End Plate	1
★	17	QB-105P17	Cylinder	1
★	18	QB-105P18	Spring Pin	1
●	19	QB-105T19	Rotor Blade (4 pcs)	1 set
▲	20	QB-105P20	Rear End Plate	1
x	21	---	Governor	1
x	22	---	Pendulum	8
x	23	---	Spring Pin	2
x	24	---	Plunger	1
x	25	---	Adjust Screw	1
x	26	---	Spring	1
x	27	---	Adjust Nut	1
●	28	QB-105P28	Ball Bearing	1
x	29	---	Bevel Pinion	1
▲	30	QB-105P30	O-Ring	1
★	31	QB-105P31	Governor Housing	1
★	32	QB-105P32	Valve Clamp	1
★	33	QB-105P33	Roller Pin	1
★	34	QB-105P34	Valve Ring	1
★	35	QB-105P35	Valve Spring	1
★	36	QB-105P36	Steel Ball	1
★	37	QB-105P37	Coil Spring	1
★	38	QB-105P38	Air Inlet Joint	1
★	39	QB-105P39	Exhaust Deflector	1
★	40	QB-105T40	Tapping Screw (2 pcs)	1 set
★	41	QB-105P41	Grease Inlet Plug	1
▲	42	QB-105P42	O-Ring	1
★	43	QB-105P43	Wheel Flange	1
★	44	QB-105P44	Rubber Shield	1
●	45	QB-105P45	Grinding Wheel (QB-905)	1
★	46	QB-105P46	Wheel Clamp	1
★	47	QB-105P47	Handle	1
★	48	QB-105P48	Wheel Wrench (A)	1
★	49	QB-105P49	Wheel Wrench (B)	1
▲	50	QB-105T50	Ball Bearing (2 pcs)	1 set
★	67	QB-105P67	Grip	1
★		QB-105T01	Governor Assembly (21.22.23.24.25.26.27)	1 set
●		QB-105T02	Bevel Gear Assembly (07.29)	1 set